



- POWERTRAIN CONTROL MODULE**
- 1 IAC COIL A HI
 - 2 IAC COIL A LO
 - 5 IAC COIL B LO
 - 6 IAC COIL B HI
 - 3 RR BANK 2 HO2S 2 LO
 - 4 RR BANK 2 HO2S 2 HI
 - 7 RF BANK 2 HO2S 2 LO
 - 8 RF BANK 2 HO2S 2 HI
 - 11 ASR ACTIVE SIGNAL
 - 12 ASR SPARK RTD SIG
 - 14 BRAKE SWITCH SIG
 - 15 PNP SW
 - 16 TRANS PRESS CTRL SOL
 - 19 LF BANK 1 HO2S 1 LO
 - 20 LF BANK 1 HO2S 1 HI
 - 17 LR BANK 1 HO2S 2 LO
 - 18 LR BANK 1 HO2S 2 HI
 - 22 TP SENSOR SIG
 - 28 TRANS RANGE SIG A
 - 29 TRANS RANGE SIG B
 - 30 TRANS RANGE SIG C
 - 23 MAP SENSOR SIG
 - 32 PCM GROUND
 - 25 ECT SENSOR SIG
 - 21 IAT SENSOR SIG
 - CONN 3

- 1 DK GRN/WHT
- 2 LT BLU
- 3 BRN
- 4 BLK/WHT
- 5 BLK/WHT
- 6 WHT
- 7 BLK
- 8 LT GRN
- 9 YEL/BLK
- 10 WHT OR GRY
- 11 BLK
- 12 GRY
- 13 GRY
- 14 PNK